

Joint Accelerator School Indore January 2008

SURFACE IMPEDANCE

Jean Delayen

Thomas Jefferson National Accelerator Facility
Old Dominion University

Definitions

- The electromagnetic response of a metal, whether normal or superconducting, is described by a complex surface impedance, $Z=R+iX$

R : Surface resistance

X : Surface reactance

Both R and X are real

Definitions

For a semi- infinite slab:

$$Z = \frac{E_x(0)}{\int_0^\infty J_x(z) dz} \quad \text{Definition}$$

$$= \frac{E_x(0)}{H_y(0)} = i \omega \mu_0 \frac{E_x(0)}{\partial E_x(z)/\partial z|_{z=0_+}} \quad \text{From Maxwell}$$

Definitions

The surface resistance is also related to the power flow into the conductor

$$Z = Z_0 \vec{S}(0_+)/\vec{S}(0_-)$$

$$Z_0 = \left(\frac{\mu_0}{\epsilon_0} \right)^{1/2} \simeq 377 \Omega \quad \text{Impedance of vacuum}$$

$$\vec{S} = \vec{E} \times \vec{H} \quad \text{Poynting vector}$$

and to the power dissipated inside the conductor

$$P = \frac{1}{2} R H^2(0_-)$$

Normal Conductors (local limit)

Maxwell equations are not sufficient to model the behavior of electromagnetic fields in materials. Need an additional equation to describe material properties

$$\frac{\partial J}{\partial t} + \frac{J}{\tau} = \frac{\sigma}{\tau} E \Rightarrow \sigma(\omega) = \frac{\sigma_0}{1 - i\omega\tau}$$

For Cu at 300 K, $\tau = 3 \times 10^{-14}$ sec
so for wavelengths longer than infrared $J = \sigma E$

Normal Conductors (local limit)

- In the local limit

$$\vec{J}(z) = \sigma \vec{E}(z)$$

- The fields decay with a characteristic length (skin depth)

$$\delta = \left(\frac{2}{\mu_0 \omega \sigma} \right)^{1/2}$$

$$E_x(z) = E_x(0) e^{-z/\delta} e^{-iz/\delta}$$

$$H_y(z) = \frac{(1-i)}{\mu_0 \omega \delta} E_x(z)$$

$$Z = \frac{E_x(0)}{H_y(0)} = \frac{(1+i)}{2} \mu_0 \omega \delta = \frac{(1+i)}{\sigma \delta} = (1+i) \left(\frac{\mu_0 \omega}{2 \sigma} \right)^{1/2}$$

Normal Conductors (anomalous limit)

- At low temperature, experiments show that the surface resistance becomes independent of the conductivity
- As the temperature decreases, the conductivity σ increases
 - The skin depth decreases
$$\delta = \left(\frac{2}{\mu_0 \omega \sigma} \right)^{1/2}$$
 - The skin depth (the distance over which fields vary) can become less than the mean free path of the electrons (the distance they travel before being scattered)
 - The electrons do not experience a constant electric field over a mean free path
 - The local relationship between field and current is not valid

$$\vec{J}(z) \neq \sigma \vec{E}(z)$$

Normal Conductors (anomalous limit)

Introduce a new relationship where the current is related to the electric field over a volume of the size of the mean free path (l)

$$\vec{J}(\vec{r}, t) = \frac{3\sigma}{4\pi l} \int_V d\vec{r}' \frac{\vec{R} [\vec{R} \cdot \vec{E}(\vec{r}', t - \vec{R}/v_F)]}{R^4} e^{-R/l} \quad \text{with } \vec{R} = \vec{r}' - \vec{r}$$

Specular reflection: Boundaries act as perfect mirrors
Diffuse reflection: Electrons forget everything

Normal Conductors (anomalous limit)

- In the extreme anomalous limit

$$\left(\frac{3}{2} \frac{l^2}{\delta_{cl}^2} \gg 1 \right)$$




Fig. 2 Anomalous skin effect in a 500 MHz Cu cavity

$$\frac{9}{8} Z_{p=1} = Z_{p=0} = \left(\frac{\sqrt{3} \mu_0^2 \omega^2 l}{16\pi\sigma} \right)^{1/3} (1 + i\sqrt{3})$$

p : fraction of electrons specularly scattered at surface

$1 - p$: fraction of electrons diffusively scattered

Normal Conductors (anomalous limit)

$$R(l \rightarrow \infty) = 3.79 \times 10^{-5} \omega^{2/3} \left(\frac{l}{\sigma} \right)^{1/3}$$

For Cu: $l/\sigma = 6.8 \times 10^{-16} \Omega \cdot \text{m}^2$

$$\frac{R(4.2 \text{ K}, 500 \text{ MHz})}{R(273 \text{ K}, 500 \text{ MHz})} = \frac{3.79 \times 10^{-5} \omega^{2/3} \left(\frac{l}{\sigma} \right)^{1/3}}{\sqrt{\frac{\mu_0 \omega}{2\sigma}}} \approx 0.12$$

Does not compensate for the Carnot efficiency

Surface Resistance of Superconductors

Superconductors are free of power dissipation in static fields.

In microwave fields, the time-dependent magnetic field in the penetration depth will generate an electric field.

$$\vec{\nabla} \times \vec{E} = -\frac{\partial \vec{B}}{\partial t}$$

The electric field will induce oscillations in the normal electrons, which will lead to power dissipation

Surface Impedance in the Two-Fluid Model

In a superconductor, a time-dependent current will be carried by the Copper pairs (superfluid component) and by the unpaired electrons (normal component)

$$J = J_n + J_s$$

$$J_n = \sigma_n E_0 e^{-i\omega t} \quad (\text{Ohm's law for normal electrons})$$

$$J_s = i \frac{2n_c e^2}{m_e \omega} E_0 e^{-i\omega t} \quad (m_e \dot{v}_c = -e E_0 e^{-i\omega t})$$

$$J = \sigma E_0 e^{-i\omega t}$$

$$\sigma = \sigma_n + i\sigma_s \quad \text{with} \quad \sigma_s = \frac{2n_c e^2}{m_e \omega} = \frac{1}{\mu_0 \lambda_L^2 \omega}$$

Surface Impedance in the Two-Fluid Model

For normal conductors

$$R_s = \frac{1}{\sigma \delta}$$

For superconductors

$$R_s = \Re \left[\frac{1}{\lambda_L(\sigma_n + i\sigma_s)} \right] = \frac{1}{\lambda_L} \frac{\sigma_n}{\sigma_n^2 + \sigma_s^2} \approx \frac{1}{\lambda_L} \frac{\sigma_n}{\sigma_s^2}$$

The superconducting state surface **resistance** is proportional to the normal state **conductivity**

Surface Impedance in the Two-Fluid Model

$$R_s \simeq \frac{1}{\lambda_L} \frac{\sigma_n}{\sigma_s^2}$$

$$\sigma_n = \frac{n_n e^2 l}{m_e v_F} \propto l \exp\left[-\frac{\Delta(T)}{kT}\right] \quad \sigma_s = \frac{1}{\mu_0 \lambda_L^2 \omega}$$

$$R_s \propto \lambda_L^3 \omega^2 l \exp\left[-\frac{\Delta(T)}{kT}\right]$$

This assumes that the mean free path is much larger than the coherence length


Surface Impedance in the Two-Fluid Model

For niobium we need to replace the London penetration depth with

$$\Lambda = \lambda_L \sqrt{1 + \xi/l}$$

As a result, the surface resistance shows a minimum when
 $\xi \approx l$

Surface Resistance of Niobium



Electrodynamics and Surface Impedance in BCS Model

$$H_0\phi + H_{ex} \phi = i\hbar \frac{\partial \phi}{\partial t}$$

$$H_{ex} = \frac{e}{mc} \sum A(r_i, t) p_i$$

H_{ex} is treated as a small perturbation $H_{rf} \ll H_c$

There is, at present, no model for superconducting surface resistance at high rf field

$$J \propto \int \frac{R[R \cdot A] I(\omega, R, T) e^{-\frac{R}{l}}}{R^4} dr \quad \text{similar to Pippard's model}$$

$$J(k) = -\frac{c}{4\pi} K(k) A(k)$$

$K(0) \neq 0$: Meissner effect

Surface Resistance of Superconductors

Temperature dependence

–close to T_c :

dominated by change in $\lambda(t) \sim \frac{t^4}{(1-t^2)^{3/2}}$

–for $T < \frac{T_c}{2}$:

dominated by density of excited states $\sim e^{-\Delta/kT}$

$$R_s \sim \frac{A}{T} \omega^2 \exp\left(-\frac{\Delta}{kT}\right)$$

Frequency dependence

ω^2 is a good approximation




Figure 4.5: Theoretical surface resistance at 1.5 GHz of lead, niobium and Nb₃Sn as calculated from program [94]. The values given in Table 4.1 were used for the material parameters.

Surface Resistance of Superconductors

- The surface resistance of superconductors depends on the frequency, the temperature, and a few material parameters
 - Transition temperature
 - Energy gap
 - Coherence length
 - Penetration depth
 - Mean free path
- A good approximation for $T < T_c/2$ and $\omega \ll \Delta/h$ is

$$R_s \sim \frac{A}{T} \omega^2 \exp\left(-\frac{\Delta}{kT}\right) + R_{res}$$

Surface Resistance of Superconductors

$$R_s \sim \frac{A}{T} \omega^2 \exp \left(-\frac{\Delta}{kT} \right) + R_{res}$$

In the dirty limit $l \ll \xi_0$ $R_{BCS} \propto l^{-1/2}$

In the clean limit $l \gg \xi_0$ $R_{BCS} \propto l$

R_{res} :

Residual surface resistance

No clear temperature dependence

No clear frequency dependence

Depends on trapped flux, impurities, grain boundaries, ...

Surface Resistance of Superconductors




Fig. 2. Temperature dependence of surface resistance of niobium at 3.7 GHz measured in the TE_{011} mode at $H_{rf} \approx 10$ G. The values computed with the BCS theory used the following material parameters:

$$T_c = 9.25 \text{ K}; \quad \lambda_L(T=0, l=\infty) = 320 \text{ \AA}; \\ \Delta(0)/kT = 1.85; \quad \xi_F(T=0, l=\infty) = 620 \text{ \AA}; \quad l = 1000 \text{ \AA} \text{ or } 80 \text{ \AA}.$$






Fig. 5. The surface resistance of Nb at 4.2 K as a function of frequency [62,63]. Whereas the isotropic BCS surface resistance (\dots) resulted in $R \propto \omega^{1.8}$ around 1 GHz, the measurements fit better to ω^2 ($- -$). The solid curve, which fits the data over the entire range, is a calculation based on the smearing of the BCS density-of-states singularity by the energy gap anisotropy in the presence of impurity scattering [61]. The authors thank G. Müller for providing this figure.

Surface Resistance of Niobium



Surface Resistance of Niobium



Super and Normal Conductors

- **Normal Conductors**
 - Skin depth proportional to $\omega^{1/2}$
 - Surface resistance proportional to $\omega^{1/2 \rightarrow 2/3}$
 - Surface resistance independent of temperature (at low T)
 - For Cu at 300K and 1 GHz, $R_s = 8.3 \text{ m}\Omega$
- **Superconductors**
 - Penetration depth independent of ω
 - Surface resistance proportional to ω^2
 - Surface resistance strongly dependent of temperature
 - For Nb at 2 K and 1 GHz, $R_s \approx 7 \text{ n}\Omega$

However: do not forget Carnot